

**MUSTANG MODEL 20/25 HYDRAULIC HAND PUMP
2-STAGE PISTON/LINKAGE ASSEMBLY
DIAGRAM "C"**

ITEM	DESCRIPTION	QTY.	PART NO.
1	Linkage Cross Arm	2	HP-120
2	Linkage Bushing	6	HP-122-3
3	Clevis - Toggle	2	HP-119-2
4	Retaining Ring	12	5100-25
5	Linkage Pin - Toggle	4	HP-110-2
6	Piston Link	2	HP-122-2
7	5/16-24 x 3/4" Sc. Hd. Cap Screw	2	34HC-1
8	Linkage Pin Pivot	2	HP-110-1
9	Clevis - Pivot	2	HP-119-1
10	7/16-20 NC x 1" Sc. Hd. Cap Screw	1	1SS-1
11	Retaining Ring	1	5008-187MD
12	Retaining Ring	1	5000-100
13	Rod Wiper 5/8"	1	U-0625
14	Wiper Gland Ring - HI Pressure	1	HPS-112
15	Backing Ring	2	8-014
16	O-Ring	2	2-014
17	O-Ring	2	2-117
18	Piston Sleeve - Hi Pressure	1	HPS-110
19	Piston Hi Pressure 5/8"	1	HPS-111
20	Rod Wiper 1 7/16"	1	940-16
21	Wiper Gland Ring - Low Pressure	1	HP-115
22	Piston Low Pressure 1 7/16"	1	HP-112
23	O-Ring	2	2-124
24	O-Ring	1	2-131
25	Piston Sleeve - Low Pressure	1	HP-114
26	Seal Kit for Model 20A Hand Pump	1	SK-20A
	Seal Kit for Model 25 Hand Pump	1	SK-25