

MUSTANG HYDRAULIC PUMP

Reservoir Assembly

DIAGRAM "D"

ITEM	DESCRIPTION	QTY.	PART NO.
1	RESERVOIR END CAP		
	20A Series Double Stage	1	HP-109
2	O-RING		
	20A Series Double Stage	2	2-236
3	O-Ring	1	3-904
4	O-Ring	1	2-015
5	Stay Bolt (Please specify for gold/black oil tank)	1	HP-121
6	Nameplate, Model, Serial No.	1	NMP-1
7	RESERVOIR		
	20A Series Model	1	HP-108-1
9	1/4-20 NC x 1 1/4" Soc. Head Cap Screw	4	114HC-8
10	O-Ring	2	3-905
11	Filler Block Vent Plug	2	HP-129
12	Check Valve Spring	2	S-60
13	Check Valve Ball, 1/4" Dia.	2	CVB-2
14	FILLER/BREATHER BLOCK		
	20A Series Double Stage	1	HP-128-2
15	Filler/Breather Gasket	1	HP-126
16	O-Ring	1	3-908
17	Filler Plug/Dipstick	1	HP-130